



No.	DESCRIPTION
2	BONNET OPERATING NUT O RING
3	BONNET
5	OPERATING NUT BEARING
7	BONNET GASKET
9	HOUSING OPERATING NUT O RING
10	BREAKING COUPLING
11	HYDRANT BODY
12	HEX HEAD BOLT & NUT (COUPLING)
13	HYDRANT BODY RING GASKET
14	HEX HEAD BOLT & NUT (INTERSECTION)
16	BREAKING FLANGE
17	STEM GUIDE
18	STEM GUIDE SET SCREW
19	INTERMEDIATE SECTION
20	DRAIN VALVE TRIPOD
21	DRAIN VALVE SCREW
22	DRAIN VALVE RIVET
23	DRAIN VALVE RUBBER
24	INTERMEDIATE GASKET
25	M.V. SEAT UPPER "O" RING
26	VALVE SEAT
27	M.V. SEAT LOWER "O" RING
29	VALVE CARRIER
30	VALVE RUBBER or BLUE POLY
31	LOWER VALVE PLATE
32	BASE (STATE INLET REQUIRED)
34	BONNET ALLEN SCREW
36	HOSE CAP GASKET
36-1	PUMPER CAP GASKET
*36-2	PUMPER CAP "O" RING, STORZ 100
*37-1	STORZ 100 PUMPER NOZZLE ST. STL.

No.	DESCRIPTION
*37-2	STORZ 100 PUMPER NOZZLE BRONZE
*38-1	STORZ 100 PUMPER CAP (INT. THREAD)
*38-2	STORZ 100 PUMPER CAP (EXT. THREAD)
40	HOSE NOZZLE CHAIN & "S" HOOK (optional)
41	PUMPER NOZZLE CHAIN "S" HOOK (optional)
43	RETAINING RING (SQUARE)
44	LOWER STEM
45	DRAIN HOLE LINING
46	DRAIN VALVE SPRING
47	FLOATING FLANGE
49	SPIROL PIN HEAVY DUTY
50	GUIDE PLATE ASSEMBLY (optional)
51	INTERIOR WRENCH (optional)
59	HYDRALUBE OPERATING NUT
60	OPERATING NUT RETAINING GLAND
61	OPERATING STEM UPPER
62	HOSE NOZZLE
62-1	PUMPER NOZZLE
63	HOSE CAP
63-1	PUMPER CAP
64	HOSE NOZZLE "O" RING
64-1	PUMPER NOZZLE "O" RING
64	GLAND OPERATING NUT "O" RING
67	NOZZLE SET SCREW
67-1	PUMPER NOZZLE PIN
*69	STORZ 65 HOSE NOZZLE
*70	STORZ 65 HOSE CAP
*71	STORZ 65 HOSE CAP "O" RING
73	COUPLING CLEVIS BOLT AND PIN
74	OIL HOLE SCREW

*OPTIONAL PARTS

